



## RFID CABINET LOCK RF-202

<b>Overview</b> .....	<b>2</b>
<b>General Introduction</b> .....	<b>2</b>
1. Unlocking Modes.....	2
<b>Getting Started</b> .....	<b>2</b>
2. Setting the management card.....	2
3. How to add the user card.....	2
4. Other features.....	3

## Overview

The RF-202 can be used for locking cabinet/drawer.

## General Introduction

### **A.Unlocking Modes.**

**There is only 1 modes of unlocking**

Normal mode: - This is also the default mode. In this mode a Card is set which is used for unlocking every time.

### **B. Getting Started**

Please insert 4 pieces of AA batteries.

2 types of card can be added.

- **Management card:** - This card is used as the first card to manage the lock and other cards. You can only add 1 management card.
- **User card:** - This card is used to unlock the lock. You can add upto 13 cards.

### **C. Setting the Management card.**

- Put a pin in reset hole (at the back of the lock body) to reset.
- You will hear a beep.
- Show the card which you want to add as the management card.
- The latch will come out
- Successfully added management card.

### **D. How to add the user card.**

- Show the management card trice.
- You will hear a beep
- Show the new card to add. This will be your User card.
- You will hear a beep implying that you have successfully added the user card.

**NOTE: You can only add upto 13 user cards.**

**Other features:-**

- **In case the management card is lost, press the reset button.**
- **The latch will stay in the lock body after resetting.**
- **Only after setting the admin card will the alarm function can activated.**
- **When u hear a beep alarm with 5 times along with green light flashing, it implies that the alarm is on.**

[www.auruslocks.com](http://www.auruslocks.com)

aurus